UNCLASSIFIED

AD NUMBER

AD827052

LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited. Document partially illegible.

FROM:

Distribution authorized to U.S. Gov't. agencies and their contractors; Critical Technology; 08 NOV 1967. Other requests shall be referred to Army Assistant Chief of Staff Force Development, FOR-OT-RD, Washington, DC 20310. Document partially illegible. This document contains export-controlled technical data.

AUTHORITY

ago d/a ltr, 29 apr 1980

THIS REPORT HAS BEEN DELIMITED

AND CLEARED FOR PUBLIC RELEASE

UNDER DOD DIRECTIVE 5200.20 AND


NO RESTRICTIONS ARE IMPOSED UPON

ITS USE AND DISCLOSURE.

DISTRIBUTION STATEMENT A

APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED.

DISCLAIMER NOTICE



THIS DOCUMENT IS BEST QUALITY AVAILABLE. THE COPY FURNISHED TO DTIC CONTAINED A SIGNIFICANT NUMBER OF PAGES WHICH DO NOT REPRODUCE LEGIBLY.

FOR OFFICIAL USE UNLY



DEPARTMENT OF THE ARMY OFFICE OF THE ADJUTANT GENERAL WASHINGTON, D.C. 20310

IN REPLY REFER TO

AGAM-P (M) (2 Feb 68) FOR OT RD-674094

6 February 1968

SUBJECT:

Operational Report - Lessons Learned, Headquarters, 35th Engineer Battalion (Cbt), Period Ending 31 October 1967

TO:

SEE DISTRIBUTION

- 1. Subject report is forwarded for review and evaluation by USACDC in accordance with paragraph 6f, AR 1-19 and by USCONARC in accordance with paragraph 6c and d, AR 1-19. Evaluations and corrective actions should be reported to ACSFOR OT within 90 days of receipt of covering letter.
- 2. Information contained in this report is provided to insure appropriate benefits in the future from Lessons Learned during current operations, and may be adapted for use in developing training material.

BY ORDER OF THE SECRETARY OF THE ARMY:

tenneth G. Neickham

KENNETH G. WICKHAM Major General, USA The Adjutant General

1 Incl

DISTRIBUTION:

Commanding Generals

US Continental Army Command

US Army Combat Developments Command

Commandants

US Army Command and General Staff College

tranomittal to

US Army War College

US Army Air Defense School

US Army Armor School

US Army Artillery and Missile School

US Army Aviation School

US Army Chemical School

US Army Civil Affairs School

US Army Engineer School

US Army Infantry School

US Army Intelligence School

US Army Adjutant General School

US Army Missile and Munitions School

US Army Southeastern Signal School

Protective marking is canceled when separated from inclosure(s)

FEB 19 1968

FOR OFFICIAL USE ONLY



ND827052

FOR OFFICIAL USE ONLY

DISTRIBUTION (Cont'd)

US Army Medical Field Service School

US Army Military Police School

US Army Ordnance School

US Army Quartermaster School

US Army Security Agency School

US Army Signal School

US Army Special Warfare School

US Army Transportation School

Copies Furnished:

Office, Chief of Staff, US Army

Deputy Chiefs of Staff

Chief of Research and Development

Assistant Chiefs of Staff

Chief of Engineers

The Surgeon General

The Provost Marahal General

Research Analysis Corporation (Library)

Defense Documentation Center

CO, 35th Engineer Battalion (Combat)

N. 114 SECTION ED SUFFICIAL SUPERING SECTION AND SECTI

FOR OFFICIAL UISE ONLY

DEPARTMENT OF THE ARMY

HEADQUARTERS 35TH ENGINEER BATT/LION (COMBAT) APO San Francisco 96238

ECD-BD-3

08 November 1967

. . 1 1/12: · ITal 100

in the str

P 98

1.1 - 1.1

... es 1708

SUBJECT: Operational Report - Lessons Learned (RCS CSFOR-65), for Quarterly Period Ending 31 October 1967

THRU:

Commanding Officer 45th Engineer Group (Const) APO 96238

Commanding General 18th Engineer Brigade APO 96377

Commanding General U.S. Army Engineer Command, Vietnam (Prov) APO 96375

Commanding General United States Army, Vietnam ATTN: AVHGC-UH APO 96307

Commander in Chief United States Army, Pacific ATTN: GPOP-OT APO 96558

TO:

Assistant Chief of Staff for Force Development Department of the Army (ACSFOR DA) Washington, D.C. 20310

FOR OFFICIAL LISE ONLY

FOR OT RD 674094

Section 1. Significant Organization or Unit Activities

1. Command: During this quarter the effect of the first aniversary of the Sattalion's arrival in Vietnam was felt. All four line companies and Headquarters Company received new company commanders. In addition, a new S-1, S-2, S-4, Property Book Officer, and Personnel Officer were appointed, of these, all but the Personnel Officer were appointed from Battalion assets. Six new lieutenants were assigned during the period, all initially as platoon leaders. The replacement system for officers has been adequate. Sufficient overlap was possible in key positions so that no loss in effectiveness occurred. The replacement of key Non-commissioned officers has also been adequate.

2. Personnel, Administration, Moral, and Discipline:

- a. The following organizational changes occurred during the reporting period:
- (1) On 21 August 1967, the Land Clearing Platoon was detached from this Bettalion and attached to the 937th Engineer Group (Const).
- (2) On 26 August 1967, the Rock Crusher Section of the 517th Engineer Company (LE) was detached from the 589th Engineer Battalion (Const) and returned to the 517th Engineer Company (LE) attached to this Battalian.
- b. During the quarter the personnel section processed 263 persons for return to CONUS for reassignment or discharge. Replacements have come in slowly and administrative adjustments were made to relieve the "rotational hump", the Battalian organic strength is down to 77% with 59 personnel of this percentage detached with the Land Clearing Platoon. Morale in the Battalian has remained high with only 3 IG complaints, 23 Class II offenses and 1 NOL. There have been 6 special Court Martials, 1 Field Grade Article 15, and 55 Company Grade Article 15's. A total of 47 awards, the Purple Heart, ACM, or the Bronze Star, were given.
- 3. Intelligence and Counterintelligence: Daily minesweeps of Highway QL-1 from LZ Hammond to the south of the Bong Son River have been conducted by assigned units throughout the report period. A daily minesweep of TL3A has been conducted since 29 September. On call minesweeps in the Bettalian AO have been performed. Significant data on enemy employment of mines and boobytraps continues to be generated and disseminated through intelligence channels. Incidents during the period included two bridges burned, three bridges partially destroyed, 4 mining incidents, one boobytrap, 11 sniper incidents, one ambush, and two mortar attacks; accounting for 14 WIA and 1 KIA to personnel in this Battalian. All possible significant intelligence data were collected from the incidents. The following significant deliberate reconnaissances were conducted during the period:
 - a. Daily reconnaissance of Highway QL-1 in Battalion AO.
 - b. Reconnaissance of possible fill sites.
 - c. Reconnaiseance of TL3A (north).
 - d. Aerial and ground reconnaissance of QL-1 from Qui Nhon to Tuy Hoa.
 - e. Aerial and ground reconnaissance of LTL6B from its north junction with CL-1 to the south junction with CL-1.

FOR OFFICER CISE ONLY

Daily intelligence data continued to be generated from local allied units and disseminated through intelligence channels.

4. Plans, Operations, and Training:

- e. The Battalion's assigned missions during this period were as follows:
- (1) LOC maintenence and upgrading of Highway QL-1 to MACV Standards from the junction of QL-1 and CL-19 to Tam Quan from 1 August 1967 to 29 September 1967.
- (2) LOC maintenance and upgrading of Highway CL-1 to MACV Standards from the Phu Tai ASP to the south bank of the Song Lai Giang (Bong Son) River BR869954) from 29 September 1967 to 31 October 1967.
- (3) Continued operational support to the 1st Air Cavalry Division (Airmobile) within the above boundaries to include the upgrading of Highway TL3A to a one-way all weather route from the junction at QL-1 to LZ Pony.
- (4) Reconnaissance of Highway OL-1 between Qui Nhon and Tuy Hoa, and of Highway LTL6B in preparation for upgrading.
 - (5) Operation of a rock crusher at the Phu Ou Pass Quarry (BR881887).
- (6) Operational support to the 7/15th Artillery Battalian at LZ Uplift and the 3/18th Artillery Battalian at LZ Pony.
- (7) Self-Help construction in support of the 41st Artillery Group at Phu Cat Airbase.
 - (8) Oulvert installation on Route 442.

(9) Operational Support to MACV Advisory at the Phu Cat Training Center.

b. Company A: Company A continues its mission of LOC upgrading of Highway QL-1 between the Phu Ly Bridge (BR885586) and Bridge QL1367 (BR932759), a distance of 10.5 miles. Fill in the amount of 52,000 cubic yards was hauled, placed compacted and shaped to being this section of road to MACV Standards. Seven miles of road received 19800 cubic yards of 3 inch (-) crushed base course in a six-dach lift and 27,250 gallons of asphelt cutback and emulsion as seal and tack coats to bring the total length of this section of road to recieve base course to 8 miles. Six of this eight mile stretch has been paved with hot-mix asphalt placed in a 24 inch layer. Due to the total asphalt requirements in this area, paving has been limited to Sunday's only. The work slong this section of road also included emplacing 180 linear feet of 24" to 60" dismeter culvert and the construction of 4 by passes. Company A constructed 4 Class 35/50 semi-permanent timber trestle bridges totaling 195 linear feet of bridging. Construction consisted of pile revetment abutments, pile bents and piers, and timber stringers and decking. Company A provided the 41st Artillery Group at Phu Cat Airbase with technical aid, material, and engineer equipment in the self-help construction of their cantonment area completing a messhall, two tropical billets; a redio repair shop, a medical station, and a TOC bunker. Company A provided security for the foot reconnaissance of LTL6B and conducted daily minesweeps of QL-1 from LZ Crystal to LZ Uplift.

FOX OFFICIAL CISE ONLY

- Company B: Company B continued to provide operational support for the 1st Air Cavalry Division (Airmobile) in the An Loa Valley and Bong Son Plains area and on Highway TL3A. The support included the construction of one timber trestle bridge of 24 feet in length and the reconstruction of a 221 foot timber trestle bridge destroyed by enemy action. On 15 August the 22! foot bridge was again destreyed by enemy action and completed again in September. Both bridges are Class 35/50 pile revetment abutment, pile bent, and timber stringer and decking bridges. In the An Loa Valley and Bong Son Plain, bulldozers worked in support of clearing operations. Construction on Highway QL-1 brought sections totaling 3 miles to MACV Standards and TL3k is presently being upgraded to an all-weather single lane route. The construction of these two routes included the emplacement of 552 linear feet of culvert, 10750 cubic yards of earth fill, 6031 cubic yards of river run fill as road sub-base, and 924 cubic yards of crushed 3"(-) base course. Company B remoyed damaged MSA1 matting from the last 1480 linear feet on the north end of English Airfield. The runway sub-base was scarified, graded, and compacted and scaled with RC-3 and sand. New matting was emplaced and anchored. The company performed a daily minesweep of QL-1 from Bong Son south to Bridge QL1374 (BR916838) and of TL3A from QL-1 to LZ Pony.
- d. Company C: Company C continued upgrading QL-1 to MACV Standards from Bridge QL1367 (ER932759) to the south bank of the Song Lai Giang River (BR869954), a distance of 13.7 miles. The construction consisted of hauling, placing, grading and compacting 67,000 cubic yards of earth fill to bring 13 miles of the company's section of road to MACV standard width. The 13 mile section received 30,000 cubic yards of 10 (-) river run as a sub-base and 28,000 cubic yards of 3 (-) crushed rock as a base course. 18,900 gallons of asphalt miulsion and cutback were spread as seal coat and tack coats. The coastruction also included the emplecement of 423 linear feet of 24" to 60" diameter culvert. Company C constructed one Class 35/50, timber trestle, pile revetment abutment, pile pier, timber stringer and decking bridge 96 feet in length. Company C also repaired Bridge OL1379 (BR879898) a 60° structure which was damaged twice through enemy action, and Bridge QL1380 (BR672913) & 40' structure damaged by enemy activity. The damage to these bridges was caused by demolitions used to gut piles and caps resulting in the need for extensive repairs. Company C also provided operational support to the 7/15th Artillery Bettalion at LZ Uplift in the construction of artillery firing platforms. The company provided one platoon for security at night at the rock crusher at the Phu Cu Page. The crusher is operated by the 517th Engineer Company (LE) under the operational control of Company C and was located at the Phu Cu. Pass to provide. crushed rock in that area. The crusher has made possible the extensive finish. roadwork disks in Company C's AO and produced 52,000 cubic yards of 3 inch (-) during the report period. Company C has conducted a daily minesweep of CL-1 from LZ Uplift to Bridge QL1374 (ER916838).
- e. Company D: Company D continued in its mission of LOC upgrading on QL-1 in its area of operation from the Phu-Tal ASP to the Phu Ly Bridge (BR885586). Company D has constructed a semi-permanent timber treatle bridges totaling 712 linear feet of bridging. Construction consisted of pile revenuent abutments, pilebents and piers, and timber or steel expingers depending on the length of spans. Company D has constructed two permanent bridges 60 feet and 120 feet in length utilizing reinforced concrete abutments, tubular steel piles for the pier on the 120 foot bridge, 36MF230 stringers, and timber decking. Company D has upgraded 7.5 miles of GL-1 by hauling, placing, shaping and compacting 28,600 cubic yards of fill, 11,600 cubic yards of 10"(-) river rum as sub-base. Two miles of this.

FOR OFFICIAL USE ONLY section have received a 6 inch lift of 3 inch (-) base course totaling 6,200 cubic yards. Asphalt cutback and emulsion in the amount of 10,500 gallons have been spread as a seal and tack coat in preparation for asphalt paving of the two mile section. Company D also performed maintenance on brides in their area constructed in 1966 and was responsible for the routine maintenance of LZ Hammond airfield. Early October rains of a higher than normal intensity caught four bridges not completed in the Company D AO and inundated the bypasses. However, due to the effort on Company D's part the road was closed only twice and then for only very short periods. The company conducted a daily minesweep of QL-1 from LZ Hammond north to LZ Crystal.

- f. 517th Engineer Company (LE): The 517th minus its third platoon has been supporting the line companies in each area of operation greatly increasing the equipment capabilities of the Battalion. The rock crusher at the Phu Qu Pass operated by the 517th along with its 290 M earth movers, bucket loaders, graders, and dozers made possible the amount of work that Company C was able to accomplish before the monsoon rains. Without the 517th's support mission, the Battalion could not have accomplished as much as it did in the amount of time alloted. The number of cranes TO&E to the 517th also increased the pile driving capability of the Battalion making possible the simultaneous construction of several bridges. In addition, the 517th has been providing operational support to the MACV Advisory Team at the Phu Cat Training Center. The construction to date includes trainfire berms, range road construction, and the placing of a concrete messhall pad. The 517th has taken over the support of the 41st Artillery Group at Ohn Cat Airbase in the construction of that cantonment area.
- 1st Platoon, 70th Engineer Company (DI): The 1st Platoon, 70th Engineer Company (DT) has greatly increased the haul capability of the Battalion. Its 24 5-ton dump trucks had a major part in the amount of fill, sub-course and base course that the Battalion was able to haul this quarter.
- Training: Battalion training during this quarter consisted mainly of unit operations and OJT. Motor stables and preventive maintenance were conducted daily. Command information classes were conducted on schedule. Other subjects taught during the period included; counter-ambush tactics, weapons familiarization, land clearing operations, care and cleaning of equipment and personal hygiene.
- 5. Logistics: During the report quarter the significant logistical operations involving the S-4 revolved around the support of the bridging portion of the LOC upgrading and operational support program. The procurement, transportation inventory and dispersement of Class IV material for bridge construction was a tramendous job and often almost impossible due to a shortage of material. On one occesion a convey was dispatched to Cam Rahn Bay to procure bridging material not available at Qui Nhon. Class I, II, III, and IV materials were procured as needed without delay at any time. The Battalica operated four water points, one at LZ Hammond, one at LZ Uplift, and two at LZ English. The Bettalion is short one weter point. During the period the 20 ton truck mounted cranes were replaced by rough terrain cranes model 2380. A total of 14 5-ton dump trucks were replaced with new trucks.

6. Force Development: During the cuarter the Bettalion provided recommendations for Modification Tables of Organization and Equipment for Engineer Combat Battalions, Corps and Army, and Engineer Light Equipment Companies. General recommendations included:

- a. Approval of "G" Series TO&E with modifications for Combat Battalion and Light Equipment Companies.
- CREATER b. Modification to "G" Series for Combat Battalians generally added great soil compaction, pile driving, and materials handling capabilities; added soil testing capability and augmented survey capability.
- c. Modification to "G" Series for Light Equipment Companies generally involved changes to reflect current issued equipment (e.g. 75TPH crusher means IN LIEU OF 25 cubic yards per hour). Increase in low bed trailers was recommended to increase mobility of the unit.
- 7. Command Management: During the quarter a major change was made in the construction management within the Battalion. Priority of construction had previously been directed towards construction of semi-permanent bridges. Due to the need for speed of construction and the need for special skills to achieve the speed, previous management techniques included assignment of all bridge construction to a single line company. Control of equipment was maintained at Battalion to best in-fluence priorities. Task assignments for other companies were directed by Battalion consistant with available equipment. The attachment of an Engineer Company (LE)(-); the approach of the end of bridge construction; the need for large scale earth moving; and the future monsoon maintenance required on the highway, all dictated a change in management structure. Each line company was assigned a new area of responsibility along the highway and all remaining bridges and earthwork within the company AO's were the responsibility of the companies concerned. Battalion influenced operations by attachment of elements of the Light Ecuipment Company and Dump Truck Platoon to line companies and by assignment of completion dates. The result of the change are to be considered excellent. Unit commanders with close personal guidance from the Battalion Commander and Operations Officer quickly learned techniques of equipment management. Units will remain responsible for all maintenance and repair in their AD during the northeast monsoon. Units are familiar enough with their areas and set up to operate independantly should they be isolated by the monsoon or enemy ection.
- 8. <u>Inspector General</u>: Inspector General activities were limited to receipt of and local action on complaints and requests for assistance by the acting Inspector General.
- 9. Information: The Battalion continued progress in the field of public information. In the expanding program the newly established special duty information specialist increased coverage of activities of the Battalian to include television, radio, and more timely photographic coverage.
- 10. Civic Affairs: In support of Revolutionary Development activities and civic action programs, elements of the Battalion continued to make progress in this area and gained increasing support from GVN officials, CIDG, RF/PF, and local Vietnamese in their desire to help and learn and their ability to provide material.

FOR OFFICIAL USE ONLY

The Battalion aided local Vietnamese at Bong Son by placing a dust palliative on their streets and in the construction of two schools. Local farmers in the area have been aided with the construction of irrigation facilities. The Battalion also aided Team #11, 41st Civil Affairs Company and local Vietnamese to construct two Class 12 bridges on Highway 504. Needed commodities have continually been donated by personnel of this Battalion to local schools and orphanages. On the Go Boi Road at Luong Cuang Hamlet, elements of this Battalion constructed blackboards and deskar for the school and supervised local citizens in the construction of a roof for the school.

Section 2, Part I, Observations (Lessons Learned).

- a. Personnel: N/A
- b. Operations:

Item: Parking on Inclines

Discussion: Operations on steep slopes requires the chocking of wheels when vehicles are stopped. To insure that chocking was used and that personnel were aware of the inherent danger of stopping without chocks, it was decided that strong positive steps needed to be taken.

Observations: We have sawed scrap 6x6 and 6x8 material for use as chock blocks when parking and made this a part of each vehicles OVM. SOP calls for using the blocks onytime the vehicle is not in use.

Item: Coordination of Construction with Advisors and Locals

Discussion: One of the major considerations for the construction of Bridge QL1330 (BR929419) was the demolition of the existing French reinforced concrete bridge. The demolition took nine days and utilized approximately 890 pounds of explosives. Due to the lengthly demolition time and the quantity of explosives necessary, public safety was a major concern. An initial contact with the An Nhon Advisory proved to be extremely valuable. Not only did they assist in notification of the local nationals of our demolition, but they also provided an interpreter for six of the nine days of demolition. The platoon leader was introduced to the local village chief who was allowed to dispose of the valuable reinforcing in a manner which benefited the vilage. On many occassions the village chief interceded on our part when it was necessary for our operation to extend into private property. The advisory provided a day security guard which was effectively intergrated into the platoon's day guard system. A Fopular Forces platoon supplied night security which was extremely valuable in that it was possible to leave materials on site which would, if not for this guard, have been stolen. This night security saved many man and equipment hours which would have been necessary to load and unload materials daily. The key element in this coordinated effort was the district advisor. We were able to perform minor engineering efforts for the accomplishment of the advisor's mission. These efforts did not interfere with our operation and aided the extention of our basic mission into the area of civic action.

FOR OFFICIAL CISE CINKY

Observation: Operations can be better scheduled and carried out when engineer personnel are not required to perform as interpreters and demolition security guards. Advisors can perform valuable services for the engineers, and, at the same time, they are furthering their own mission.

Item: Outs in Bypasses

Discussion: Bridge construction along Highway OL-1 necessitated the construction of byprases around the gaps to maintain a continuous flow of traffic during the construction of timber trestle bridges. After completion of the bridges, many of the bypasses were cut in a hasty manner with a DTE dozer or other piece of equipment to salvage the culvert and allow for freer passege of water through the constructed area. The insecure nature of the operations prevents complete removal of the bypasses since destruction of the bridge may necessitate a rapid replacement of a cut bypass. To preclude the possibility of excessive loss in replacement of a cut out bypass, care should be used in the initial cutting of the bypass. By cutting a bypass with a clamshell or a backhoe, and placing the removed fill on the bypass several advantages can be obtained. A roadblock will be formed preventing anyone driving into the cut and a neat cut will facilitate any construction and replacement of a culvert. Also, a ready supply of fill will remain available to push over the culvert thereby eliminating the need for a long fill haul to install the culvert.

Observation: Care taken in cutting bypasses around completed bridges can save unnecessary manhours, equipment hours and materials in replacing the bypass should the bridge be destroyed.

Item: Use of 290M's to Haul Stockpiled Crushed Rock.

<u>Discussion</u>: Recent use of a 75TPH crusher to crush river run rock resulted in the creation of a stockpile that would build up faster than a front loader and a 5 ton dump truck could haul the read away. Clark 290M's were substituted for the front loader and the 5 tons. By reshaping the stockpile with a D7E dozer, the Clark 290M's were able to pick up the crushed rock and haul it to a laydown site. This provided an efficient means of removing rock from the stockpile, and released a front loader and 5 ton trucks for employment elsewhere.

Observation: Clark 290H's and a DTE dozer can be efficiently employed in the removal of stockpiled crushed rock.

Item: Numbering Decking and Treadway During Reconstruction of Damaged Bridges.

Discussion: Recent incidents of timber pile bridge damage by VC/NVA units were of the following nature: two or three center piles of the intermediate bent were blown, cutting the cap and leaving the remainder of the bridge undamaged but incapable of handling military traffic. The repairs necessitated the complete removal of two spans of the bridge, replacement of the piles and the cap, replacement of the remainder of the spans. During one repair of this type, decking and treadway were rulled up without being marked. Replacing this decking ind treadway became a maze of confusion and a great deal of additional material was required to replace that which did not fit properly or had to be cut. During a later repair of the same type, a system was devised of marking the pieces using letters from left to right and numbers from front to back. By using this system, it was possible to replace the decking and treadway with a minimum of waste and replacement of materials.

Observation: "unipring i tradimity and looking before removal from a damaged bridge can expedite replacement with a minimal waste of materials.

Item: M8A1 Matting

<u>Discussion</u>: In the placing of long stretches of M8A1 matting dering the repair of English Airfield, it was noted that the matting had a tendency to angle from the strip centerline.

Observation: It was discovered that the matting could be straightened appreciably by utilizing two pieces of matting, modified by attaching lifting shackles to permit the attachment of a chain, which were attached to in place matting on either side of the runway and pulled by 5-ten trucks. This was done after every 10-12 rows of matting and had the added effect of tightening as well as realigning the matting.

Item: Timber Trestle Bridge

Discussion: Bridge QL1391, located near Tam Quan, proved to be a regular target for Viet Cong activity. It was burned on two occasions and as a result provided a significant obstacle to northbound traffic. In order to provide a firebreak, the center span of the 221 foot bridge was constructed completely of steel components. Two hollow steel pile bents of four piles each were driven and filled with concrete, the piles were then capped with steel I-beams and steel stringers six feet in length were placed. The decking consisted of 3/4 inch steel plate placed across the stringers.

Observation: This method was utilized to prevent a fire starting on one half of the bridge from consuming the entire structure. An additional benefit arising from this method of construction is that the steel span can be used as an intermediate support for a Beiley Bridge in the event one was required across the entire 200 foot gap.

Item: Timber Trestle Bridge

Discussion: When Bridge QL1391 was burned initially the high level of the water under the bridge prevented the piles from being burnt completely to the ground. This provided the opportunity to cut the existing pile stubs level and placing a 12x12 sill across them on which a post bent could be constructed. Adjacent bents were then braced together to provide longitudinal stability.

Observation: This method of construction saved considerable time in that the majority of the bents did not require new piles to be driven. This was exceptionally critical at this time due to a general lack of piles and pile driving equipment within the Battalion.

Item: Upgrading of Drainage Structures

Discussion: When an inadequate culvert is replaced by a bridge or a larger culvert in a different but nearby location, damage can be caused to the irrigation system of the local farmers. Often the local farmer will attempt to reopen the original culvert, causing damage to the road.

Observation: Care must be taken when upgrading culverts so as not to damage the local irrigation system. The bottom of the new culvert must be at least as low as the original one replaced and preferably along the same center line.

Item: Driving Piles into Deep Nater with Rock in River Bottom

Discussion: It is difficult to drive piles straight through rocky soil, especially when buried under fifteen to twenty feet of water.

Observations Pushing loose fill into the gap and driving the piles through the loose fill and into the material below results in a straight pile. The loose fill has a negligible effect on pile penetration but provides enough lateral support to keep the pile straight when going through a rocky river bottom.

Item: River Run Rock

Discussion: In the construction of sub-base and base course on QL-1 it became necessary to find a ready source of rock for sub-base as available crushers in the area were committed to the maximum production of 3 inch (-) base course. Two seprete river run gravel sites were located in stream beds in the Cha Rang Velley and just north of the Phu Cu Fass. The river run was loaded into dump trucks by fact and also loaded by 290-M scrapers. It was found that well graded material including rock as large as 20 inch(-) could be put down on the shoulders of the road and 10 inch (-) elsewhere. On over 16 miles of road the river run was placed as a sub-base and it has proven to be highly satisfactory in this application. At the Phu Cu Pess, river run rock with sandy fines was fed into the crusher to produce 3 inch (-) base course and further proved the versatility of this resource. It has excellent compaction and surface wearing characteristics accepting an asphalt surface seal with good results

Observation: River run rock is readily available in many stream beds in Vietnam and can be highly valuable to engineers. As the streams dry up after the monsoens, possible river run sites should be located as gravel resources for engineers in heavy construction as well as raw material for crusher sites.

- c. Training and Organization: N/A
- d. <u>Intelligence</u>:

Item: Bridge Security

Discussion: Bridges along Route QL-1 that do not have permanent security provided can be expected to be destroyed, especially more critical bridges where bypesses are difficult. Bridge QL1391 has been destroyed twice, Bridge QL1387 destroyed and damaged once, Bridge QL1380 damaged once, Bridge QL1379 damaged twice, and Bridge QL1343 destroyed.

Observation: Bailey Bridges at QL1389 and QL1386 and the Phu Ly Bridge (QL1346) have not been damaged. These bridges have a permanent guard established on them. This security is a must for all bridges.

FOR OFFICIAL LISE ONLY

e. Logistics: N/A

f. Other:

Item: Starting Motor Rough Terrain Cranes

<u>Discussion</u>: Considerable difficulty was experienced with the starting motor for the crane engine of the Rough Terrain Crane. The starter was inferior in design and several failures were experienced.

Observation: We found that the starting motor for the Allis Chalmer HD16M me dium tractor fit perfectly on the Rough Terrain Crane. No further difficulty has been experienced with this change and an EIR has been subsequently forwarded through channels.

Section 2, Part II, Recommendations:

- 1. It is recommended that attention be given to the lack of compaction equipment allocated to a combat engineer battalion under the "E" series TO&E. Extensive road upgrading is being undertaken by engineer units in Vietnam, and proper compaction is the key to any road especially with the climate conditions existing in Vietnam. The lack of proper compaction equipment has resulted in road failures in many instances where they could otherwise have been avoided. The compaction equipment is needed not only for road construction, but in any type of construction requiring a stablized base such as airfields, helipads and storage areas.
- 2. It is recommended that any LOC upgreding plans include a detailed plan for security of key bridges constructed in insecure areas. Security plans must be made at the earliest possible time, preferably during long range planning stages. It is evident from the number of bridges destroyed in this Battalian's AO that such a plan is needed.

DAVID N. HUTCHISON

LTC, CE Commanding

//

MGD-3

1st Ind

SUBJECT: Operational Report - Lessons Learned (RCS CSFOR-65), for Quarterly Period Ending 31 October 1967.

HEADQUARTERS, 45TH ENGINEER GROUP (CONST), APO 96238, 22 November 1967

THRU: Commanding General, 18th Engineer Brigade, ATTW: AVBC-C, APO 96377

Commanding General, USA Engineer Command Vietnam (Prov)

ATTN: AVCC-PGO, APO 96491

Commanding General, United States Army, Vietnam, ATTN:

AVHGC-DH, APO 96307 Commander in Chief, United States Army, Pacific, ATTM:

GROP-OT, APO 96558

TO: Assistant Chief of Staff for Force Development, Department of the Army (ACSFOR DA), Washington, D.C. 20310

1. Operational Report-Lessons Learned of the 35th Engineer Battalion (Combat) for the Quarterly Period ending 31 October 1967 is forwarded.

2. Concur with observations.

Colonel, Corps of Engineers

Commanding

FOR OFFICIAL USE ONLY

AVBC-C (8 Nov 67)

2nd Ind

CPT Storat/dne/DBT-163

SUBJECT: Operational Report - Lessons Learned (RCS CSFCR-65), for

Quarterly Period Ending 31 October 1967

23 NOV 1967

Headquarters, 18th Engineer Brigade, APO 96377

TO: Commanding General, U.S. Army Engineer Command, Vietnam (Prov) ATTN: AVCC-P&O, APO 96375

- 1. This headquarters has reviewed the report submitted by the 35th Engineer Battalion (C) (A), as indorsed, and considers it an accurate and excellent description of the unit's activities and accomplishments during the reporting period ending 31 October 1967.
- 2. Concur with the recommendations of the Battalion Commander with the following comment added:

Reference Section 2, Part II, para 1. Standardized MTOE 5-36G submitted to USAECV(P) on 20 October 1967 requested increased allowances of towed compaction equipment in the Equipment Platoon of Headquarters & Headquarters Company. Standardized MTOE 5-58G submitted at the same time requested increased allowances of self-propelled compaction equipment for the Light Equipment Company.

1 Incl nc

Colonel Deputy Commander

PROTECTIVE MARKING CANCELLED WHEN SEPARATED FROM BASIC DOCUMENT.

FOR OFFICIAL USE ONLY

AVCC-P&O (8 Nov 67) SUBJECT: Operational Report - Lessons Learned (RCS-CSFOR-65), for Quarterly Period Ending 31 October 1967

HEADQUARTERS, UNITED STATES ARMY ENGINEER COMMAND VIETNAM (PROV) APO 96491 **8 DEC 1967**

TO: Commanding General, United States Army Vietnam, ATTN: AVHGC-DH

This headquarters concurs with the 35th Engineer Battalion's CELL report and previous indorsements as written, subject to the following comments:

Reference Section 2, Part II, paragraph 2, page 11, item concerning LOC upgrading plans: Current bridge designs include protective devices and bunkers where appropriate.

FOR THE COMMANDER:

Colonel, Chief of Staff

Info cys furn:

CG, 18th Engr Bde CO, 45th Engr Gp CO, 35th Engr Bn

THIS MARKING IS CANCELLED WITH SEPARATED FROM THE MATERIAL BEARING A PROTECTIVE MARKING

14

14

AVHGC-DST (8 Nov 67)

SUBJECT: Operational Report - Lessons Learned (RCS CSFOR-65), for Quarterly Period Ending 31 October 1967

HEADQUARTERS, UNITED STATES ARMY VIETNAM, APO San Francisco 96375 2 JAN 1968

TO: Commander in Chief, United States Army, Pacific, ATTN: GPOP-DT, APO 96558

- 1. This headquarters has reviewed the Operational Report-Lessons Learned for the period ending 31 October 1967 from Headquarters, 35th Engineer Battalion (Combat) (AZ5A) as indorsed.
 - 2. Concur with report as indorsed. Report is considered adequate.

FOR THE COMMANDER:

JOHN V. GETCHELL

Captain, AGC

Assistant Adjutant General

Copies furn:

HQ, 35th Engr Bn (Combat)

HQ, USAECV (P)

GPOP-DT(8 Nov 67)

5th Ind

SUBJECT: Operational Report for the Quarterly Period Ending 31 October 1967 from HQ, 35th Engr Bn (Cbt) (UIC: WAZSAA) (RCS CSFOR-65)

HQ, US ARMY, PACIFIC, APO San Francisco 96558 12 JAN 1968

TO: Assistant Chief of Staff for Force Development, Department of the Army, Washington, D. C. 20310

This headquarters has evaluated subject report and forwarding indorsements and concurs in the report as indorsed.

FOR THE COMMANDER IN CHIEF:

HEAVRIN SNIDER

CPT, AGC

Asst AG

Secunty Classification		ent to a supple services.
	ONTROL DATA - R & D - ret apporter, a quart he interest whom it is avoid the next it is classific.	· 11
ORIGINATING ACTIVITY (Composte estima)	20. REPORT SECURITY CLASSIFICAT	107.
OACSFOR, DA, Washington, D. C. 20310	For Official Use On	<u>1y</u>
REPORT TITLE		
Operational Report - Lessons Learned, He	addustrare 35th Fredrices Battellies (Che	`
l september and searched, her	addancers, Soun Engineer Dattation (CDC	,
DESCRIPTIVE NOTES (Type of report and inclusive dates)		
Experiences of unit engaged in countering. Authorisi (First name, middle initial, last name)	nsurgency operations, 1 Aug - 31 Oct 196	/
CO, 35th Engineer Battalion (Combat)	•	
REPORT OATE	78. TOTAL NO. OF PAGES 75. NO. OF REFS	
8 November 1967	17	
A. CONTRACT OR GRANT NO.	98. ORIGINATOR'S REPORT NUMBER(S)	
B. PROJECT NO.	674094	•
N/A		
e. N/A	9b. OTHER REPORT NO(S) (Any other numbers that may be this report)	assigne
4		
6. DISTRIBUTION STATEMENT		
1. SUPPLEMENTARY NOTES	12. SPONSORING MILITARY ACTIVITY	
N/A ·	OACSFOR DA Washington D C 2021	n
.,	OACSFOR, DA, Washington, D. C. 20310	J
I. ABSTRACT		
•	,	
	·	
•		
*	•	
	•	
	•	
•		
. 17		
. 17		
. 17		
. 17		

UNCLASSIFIED

DD . FORM .. 1473